



Product Data Sheet

Product # 7005SPRING

SPRING FRESH

Odor Counteractant & Deodorizing Cleaner

With a soothing spring like aroma, this concentrated, water soluble liquid deodorizer stops odors caused by mold, mildew, pets, urine and much more. Perfect for use anywhere odors are a problem such as homes, boats, cars, bathrooms, kitchens, garbage bins, nursing homes, gyms, prisons, etc. This product may be used for general cleaning to deliver a scent of spring as you as soiled hard surfaces become clean. Spring Fresh is specially formulated to be non-staining.

USES

- Restrooms
- Animal quarters
- Garbage Containers
- Floors
- Vehicles
- Carpet Freshening
- Cigarette Urns

FACILITIES

- Hotels
- Nursing homes
- Day Cares
- Office Buildings
- Schools
- Animal Care

BENEFITS

- Immediate relief of mal odors
- Pleasant soothing aroma
- Dilutable for good hard surface cleaning.
- One step cleaning, deodorizing

PHYSICAL PROPERTIES

Appearance – Clear liquid
Foaming – Moderate
Fragrance – Spring-Like Aroma
Specific Gravity @ 25° C – 0.997
Flash Point (TCC) – 154° F
PH – 6-7 Typical
Wetting – Good
Biodegradable -Yes

SAFETY

Caution: This product contains ingredients that can cause severe eye irritation. Wear safety glasses and suitable gloves. Do not excessively inhale vapors.

FIRST AID:

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

IF ON SKIN: Gently wash with plenty of soap and water

IF INHALED: If breathing is difficult, remove victim to fresh air and keep at rest in a position comfortable for breathing.

IF SWALLOWED: Call a POISON CENTER or doctor/physician if you feel unwell.

Obtain Safety Data Sheet (SDS) for detailed safety information.

STORAGE

Store in a cool, dry, well-ventilated area away from sunlight, heat and ignition sources. Store above 41 degrees F, and below 127 degrees F

DIRECTIONS FOR USE

Read product label and SDS before use.

METHOD OF APPLICATION

Mal Odor Counteractant

1. Remove odor source: To effectively counteract mal odors, the source of the odor should be removed. In heavily soiled areas, pre clean with a heavy duty cleaner such as Emtech Labs' EM-1. Rinse before applying this product.
2. For small areas: Apply this product non-diluted by fine mist spray, or trigger spray. For large areas: Apply non-diluted by pump spray, atomizer, mister, or fogger.
3. **Caution, sprayed surfaces will be wet.** Wipe surface dry with a damp clean cloth. On floors, damp mop dry.

Deodorizing & Hard surface cleaning

1. Sweep floor of any loose debris.
2. Dilutions: Mild odor problems: 2-4 ounces per gallon. Moderate odor problems: 6-10 ounces per gallon. Severe odor problems: 12-22 ounces per gallon.
3. Clean with microfiber towel, brush, sponge, mop, or other tools as prescribed by the end user management. Clean water rinse if needed.

Emtech Laboratories, Inc.

580 Cemetery Street • Norcross, GA. 30071

(770) 446-7118 (770) 446-1741 Fax

www.emtechlabs.com

AVAILABLE IN

8 oz. Fine Mist Spray Bottles, 12, 24, or 35 per case
Quart Case of 12

Gallon Case of 4

Pails: 5,

Drums: 20, 30, 35, and 55 Gallon Plastic Drums

Tote Tank: 275 Gallon Plastic

Revision Date: 08/14/17